

Specifications*

ITEM	SL-26SL	SL-30SL
Platform Size (Inside Toeboards) Standard w/ Extension	67.5 in. x 141.5 in. [1.71 m x 3.59 m] 67.5 in. x 181.5 in. [1.71 m x 4.61 m]	67.5 in. x 166.25 in. [1.71 m x 4.22 m] N/A
Max. Platform Capacity Standard w/ Extension on Extension	1500 lbs. [680 kg] 1500 lbs. [680 kg] 500 lbs. [227 kg]	1300 lbs. [590 kg] N/A N/A
Max. No. of occupants Standard on Extension	5 people 2 people	5 people N/A
Height Working Height Max. Platform Height Min. Platform Height	32 ft. [9.75 m] 26 ft. [7.93 m] 59 in. [1.5 m]	36 ft. [10.97 m] 30 ft. [9.14 m] 59 in. [1.5 m]
Dimensions Weight Overall Width Overall Height Overall Length	Kohler Gas: 6,590 lbs. [2989 kg] Kubota Gas: 6,720 lbs. [3048 kg] Kubota Diesel: 6,780 lbs. [3075 kg] 84 in. [2.13 m] 102.5 in. [2.60 m] 149 in. [3.79 m]	Kohler Gas: 6,900 lbs. [3130 kg] Kubota Gas: 7,030 lbs. [3189 kg] Kubota Diesel: 7,090 lbs. [3216 kg] 84 in. [2.13 m] 102.5 in. [2.60 m] 173 in. [4.39 m]
Driveable Height	26 ft. [7.93 m]	30 ft. [9.14 m]
Surface Speed Platform Lowered Platform Raised	0 to 3.1 mph [0 to 5.0 km/h] 0 to .5 mph [0 to .8 km/h]	0 to 3.1 mph [0 to 5.0 km/h] 0 to .5 mph [0 to .8 km/h]
System Voltage	12 Volt DC	12 Volt DC
Hydraulic Tank Capacity	12 Gallons [45.5 l]	12 Gallons [45.5 l]
Maximum Hydraulic System Pressure	2500 psi [172 bar]	2500 psi [172 bar]
Hydraulic Fluid Normal Use (>32 °F [0 °C]) Low Temp. Use (-10 to 32 °F [-23 to 0 °C])	ISO #46 5W-20 Motor Oil	ISO #46 5W-20 Motor Oil
Lift System	One Single Stage Lift Cylinder	One Single Stage Lift Cylinder
Lift Speed	Raise, 21 sec./Lower, 32 sec.	Raise, 24 sec./Lower, 36 sec.
Platform Leveling	13° Side/Side, 9° Fore/Aft	13° Side/Side, 9° Fore/Aft
Power Source	20 HP Kohler Magnum, 20 HP Kubota WG750, 20 HP Kubota D905 (Diesel)	20 HP Kohler Magnum, 20 HP Kubota WG750, 20 HP Kubota D905 (Diesel)
Control System	Proportional Joystick w/Interlock	Proportional Joystick Controls w/Interlock
Horizontal Drive	Four Wheel, Hydraulic Motors	Four Wheel, Hydraulic Motors
Tires	26 x 12.00 - 12 NHS Super Terra-grip with Trac Seal	26 x 12.00 - 12 NHS Super Terra-grip with Trac Seal
Parking Brakes	Two, Spring Applied, Hydraulic Release, Multiple Disc	Two, Spring Applied, Hydraulic Release, Multiple Disc
Turning Radius (inside)	13 ft. [3.96 m]	13 ft. [3.96 m]
Maximum Gradeability	35% [19°]	35% [19°]
Wheel Base	100 in. [2.54 m]	100 in. [2.54 m]
Guardrails	43.5 in. [1.11 m] high, Fold Down with Gate	43.5 in. [1.11 m] high, Fold Down with Gate
Toeboard	6 in. [152 mm] High	6 in. [152 mm] High

* Specifications subject to change without notice.

Hot weather or heavy use may reduce performance.

Meets or exceeds all applicable requirements of OSHA and ANSI A92.6-1999.

Refer to Service Manual for complete parts and service information.

FOR MORE INFORMATION



Local Distributor:

TEL: (800) 926-5438 or (559) 891-5200
FAX: (559) 896-9012
PARTS: (888) UR-PARTS
PARTSFAX: (559) 896-9244
1775 Park St., Selma, CA 93662
http://www.upright.com

UpRight
Operator Manual

SL-26/30SL

SERIAL NO. 13300 to Current


WARNING

All personnel shall carefully read, understand and follow all safety rules, operating instructions and the Scaffold Industry Association's MANUAL OF RESPONSIBILITIES (ANSI A92.6) before operating or performing maintenance on any UpRight aerial work platform.

SAFETY RULES



NEVER operate the machine within ten feet of power lines. THIS MACHINE IS NOT INSULATED.



NEVER elevate or drive elevated on uneven slopes or soft ground or elevate the platform unless the platform is level.



NEVER sit, stand or climb on guardrail or midrail.

NEVER operate the machine without first surveying the work area for surface hazards such as holes, drop-offs, bumps and debris before operating machine.

NEVER operate the machine if all guardrails are not properly in place and secured with all fasteners properly torqued.

SECURE gate across entrance after mounting platform.

NEVER use ladders or scaffolding on the platform.

NEVER attach overhanging loads or increase platform size.

LOOK up, down and around for overhead obstructions and electrical conductors.

CHECK all four tires for correct inflation. See Specifications.

DISTRIBUTE all loads evenly on the platform. See the back cover for maximum platform load.

NEVER use damaged equipment. (Contact UpRight for instructions, see toll free number on back cover.)

NEVER change operating or safety systems.

INSPECT the machine thoroughly for cracked welds, loose hardware, hydraulic leaks, damaged control cable, loose wire connections and wheel bolts.

NEVER climb down elevating assembly with the platform elevated.

NEVER perform service on machine while platform is elevated without blocking elevating assembly.

NEVER recharge batteries near sparks or open flame; batteries that are being charged emit highly explosive hydrogen gas.

AFTER USE secure the work platform against unauthorized use by turning key switch off and removing key.

NEVER replace any component or part with anything other than original UpRight replacement parts without the manufacturers consent.

California Proposition 65 Warning

Gasoline and diesel engine exhaust and some of their constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Introduction

This manual covers SL-26/30 Speed Level Work Platforms. **This manual must be stored on the machine at all times.**

Pre-Operation and Safety Inspection

Read, understand and follow all safety rules and operating instructions and then perform the following steps each day before use.

- 1. Remove module covers and inspect for damage, oil leaks or missing parts.
- 2. Check the level of the hydraulic oil with the platform fully lowered. Oil should be visible in the sight gauge. Add hydraulic oil, if necessary (see Specifications, back cover).
- 3. Check that the fluid level in the battery is correct (see Battery Maintenance, page 7).
- 4. Carefully inspect the entire work platform for damage such as cracked welds or structural members, loose or missing parts, oil leaks, damaged cables or hoses, loose connections and tire damage.
- 5. Check that all guardrails are securely in place with all fasteners properly torqued.
- 6. Check tire pressure (50 psi).
- 7. Position the Chassis Emergency Stop Switch to ON, open the switch guard and push the switch toward the guard.

Gasoline / Propane Model Inspection

- 1. Check fuel supply.
- 2. Check engine oil level with dipstick.
- 3. Set Fuel Selector Switch to desired position. Set to the center position to purge the system when switching fuels. If the machine is to be operated on propane, open the supply valve on the tank.
- 4. If equipped, check coolant level in radiator. DO NOT check coolant when radiator or engine is hot.

NOTE: When using LP gas, use clean, water free liquid petroleum gas, preferably from a bulk storage tank. Follow the instructions located on the Power Module tray for filling the tank.

!

WARNING

!

If you smell propane, close the supply valve on the tank immediately until you have located and corrected the leak.

Diesel Model inspection

- 1. Check fuel supply.
- 2. Check engine oil level with dipstick.
- 3. While the engine is cool check the radiator coolant level. **DO NOT** check coolant when the engine or radiator is hot.

System Function Inspection

!

WARNING

!

STAND CLEAR of the work platform while performing the following checks.

Before operating the work platform survey the work area for surface hazards such as holes, drop-offs, bumps and debris.

Check in ALL directions, including above the work platform, for obstructions and electrical conductors.

Protect control console cable from possible damage while performing checks.

- 1. Unhook Controller from front guardrail. Firmly grasp Controller hanger in such a manner that the Interlock Lever can be depressed, while performing the following checks from the ground.
- 2. Pull Controller Emergency Stop Button out to ON position.
- 3. Turn Controller Key Switch fully clockwise to start the engine, releasing the key once the engine starts.

Note: If the engine is cold, depress the choke button and hold while starting. Diesel models: depress and hold the glow plug button for 6 seconds prior to starting to engage the glow plugs.

- 4. Place Drive/Level/Lift Switch in **DRIVE** position.
- 5. With the Speed Range Switch first in **HIGH TORQUE** and then in **HIGH SPEED** actuate the Interlock Lever and slowly push the Control Lever to **FORWARD** then **REVERSE** positions to check for speed and directional control. The farther you push or pull the Control Lever from center the faster the machine will travel.




Figure 1: Chassis, Left Side

NOTES:

NOTES:

6. Push Steering Switch **RIGHT** then **LEFT** to check for steering control.
7. Place Drive/Level/Lift Switch to **LEVEL**. While depressing Interlock Lever actuate the Fore/Aft and Side/Side Switches to verify they function properly. Use the Side/Side Switch and tilt the platform to one side.
8. Rehook Controller on guardrail.
9. Push Chassis Lift Switch to **UP** position and elevate platform. The platform should only elevate to the interlock height, about 8 feet (2.44 m) above the ground, and the Tilt Alarm should sound. If the platform continues to elevate and/or there is no alarm **STOP** and remove the machine from service until repaired.
10. Lower the platform with the Chassis Lift Switch.
11. Enter the platform. Using the bubble level as a guide level the platform with the Side/Side and Fore/Aft Switches. Dismount platform.
12. Fully elevate platform using Chassis Lift Switch.
13. Visually inspect the elevating assembly, lift cylinder, cables and hoses for damage or erratic operation. Check for missing or loose parts.
14. Lower the platform partially by pushing Chassis Lift Switch to **DOWN**, and check operation of the audible lowering alarm.
15. Open the Chassis Emergency Lowering Valve, push in and turn counterclockwise, to check for proper operation. Once the platform is fully lowered, close the valve, push in and turn clockwise until the detent engages.
16. Close and secure module covers.
17. Turn the Controller Key Switch counterclockwise to OFF and push the Emergency Stop Switch Button to OFF.




Figure 2: Controller

Operation

Before operating work platform, ensure that the pre-operation and safety inspection has been completed, any discrepancies have been corrected and the operator has been thoroughly trained on this machine.

Travel With Platform Lowered

1. Verify Chassis Emergency Stop Switch is in the ON position. Open the switch guard and push the switch toward the guard.
2. After mounting platform, close and latch gate. Check that guardrails are in position and properly assembled with fasteners properly torqued.
3. Check that route is clear of persons, obstructions, holes and drop-offs and is capable of supporting the wheel loads.
4. Check clearances above, below and to the sides of the platform.
5. Pull Controller Emergency Stop Button out to ON position.
6. Turn Controller Key Switch fully clockwise to start the engine, releasing the key once the engine starts.

Note: If the engine is cold, depress the choke button and hold while starting. Diesel models: depress and hold the glow plug button for 6 seconds prior to starting to engage the glow plugs.

7. Set the Drive/Lift Speed Range Switch to **HIGH TORQUE**.
8. Grasp the Control Lever so the Interlock Lever is depressed (releasing the Interlock Lever cuts power to Controller). Slowly push or pull the Control Lever to **FORWARD** or **REVERSE** to travel in the desired direction. The farther you push or pull the Control Lever from center the faster the machine will travel.
9. While moving, push the Drive/Lift Speed Range Switch to **HIGH SPEED** for travel on level surfaces or to **HIGH TORQUE** for climbing grades or traveling in confined areas.

Steering

1. Push the Steering Switch **RIGHT** or **LEFT** to turn the wheels. Observe the tires while maneuvering to insure proper direction.
- NOTE: Steering is not self-centering. Wheels must be returned to the straight ahead position by operating the Steering Switch.**

Leveling Platform

With Drive/Level/Lift Switch in **LEVEL** hold the Control Lever so the Interlock Lever is depressed. Center bubble in bubble level using Fore/Aft and Left/Right Switches. To level the platform forward it may be necessary to elevate the platform slightly.

Raising and Lowering The Platform

1. Position the Drive/Level/Lift Switch to **LIFT**.
2. While holding the Control Lever so the Interlock Lever is depressed, push the Control Lever slowly to **UP** to raise the platform. Pushing the Control Lever farther increases the lift speed. If the platform does not elevate above the interlock height, about eight feet (2.44 m), fully lower platform and re-level.
3. When the work task is completed, position the Drive/Level/Lift Switch to **LIFT** and lower the platform by pulling back on the Control Lever until the platform is fully lowered.

Travel With Work Platform Elevated

Travel with platform elevated **ONLY** on firm flat surfaces.

NOTE: The Work Platform will travel at reduced speed when in the elevated position.

1. Check that the route is clear of persons, obstructions, holes and drop-offs, is level and capable of supporting the wheel loads.
2. Check clearances above, below and to the sides of platform.
3. Position the Drive/Level/Lift Switch to the **DRIVE** position.
4. Push the Control Lever to **FORWARD** or **REVERSE** for the desired direction of travel.

If the machine quits driving and the Tilt Alarm sounds, immediately lower and re-level the platform before attempting to elevate again.

Emergency Lowering

The Emergency Lowering Valve is located on the left hand side of the chassis through the cutout in the Control Module cover.

1. Open the Emergency Lowering Valve by pushing in and turning the knob counterclockwise approximately $\frac{1}{4}$ turn, the knob will pop out, disengaging detent.
2. Once the platform is fully lowered, be certain that the Emergency Lowering Valve is closed again. The platform will not elevate if the Emergency Lowering Valve has not been closed.
3. To close the Emergency Lowering Valve, push the knob in and turn approximately $\frac{1}{4}$ turn clockwise until the detent engages.

Switching Fuels (Gasoline / Propane Only)

1. With engine running push the Fuel Selector Switch to the center position.
2. After the engine has quit running select the appropriate fuel supply.
3. Restart the engine.

After Use Each Day

1. Ensure that the platform is fully lowered.
2. Park the machine on level ground, preferably under cover, secure against vandals, children or unauthorized operation.
3. Turn the Key Switch to **OFF** and remove the key to prevent unauthorized operation.

Parking Brake Release (Figure 3)

Perform the following only when the machine will not operate under its own power and it is necessary to move the machine or when towing the machine up a grade or winching onto a trailer to transport.

1. Close the needle valve by turning the knob clockwise.
2. Pump the Brake Release Pump until the Parking Brakes release and the wheels can be turned.
3. The machine will now roll when pushed or pulled.
4. Be sure to open the needle valve and verify that the Parking Brakes have engaged before the machine is operated.






Figure 3: Brake Release Pump



Routine Service

Use the following table as a guide for routine main-tenance. **Inspection and maintenance shall be performed by personnel who are trained and familiar with mechanical and electrical proce-dures.** Refer to the Service Manual for complete service instructions.

Please copy this page and use the Routine Service Table as a checklist when inspecting a machine for service.

COMPONENT	INSPECTIONORSERVICES	INTERVAL	Y	N	R
Engine Oil	Check level and condition	Daily			
	Check for leaks	Daily			
	Change oil & filter (Dual Fuel)	30D			
	Change oil & filter (Diesel)	100 HOURS			
Engine Fuel System	Check fuel level	Daily			
	Check for leaks	Daily			
	Replace fuel filter	6M			
	Check air cleaner	Daily			
Engine Battery System	Check electrolyte level	Daily			
	Check specific gravity	30D			
	Clean exterior	6M			
	Check battery cable condition	Daily			
Engine Coolant (Diesel)	Clean terminals	6M			
	Check coolant level (with engine cold)	Daily			
Hydraulic Oil	Replace coolant	3M			
	Check oil level	Daily			
Hydraulic System	Change filter	6M			
	Drain and replace oil	2Y			
	Check for leaks	Daily			
	Check hose connections	30D			
Emergency Hydraulic System	Check hoses for exterior wear	30D			
	Open the emergency lowering valve and check for serviceability	Daily			
Controller	Check switch operation	Daily			
Control Cable	Check the exterior of the cable for pinching, binding or wear	Daily			
Platform	Check fasteners for proper torque	Daily			
Deck and Rails	Check welds for cracks	Daily			
	Check condition of deck	Daily			
Tires	Check for damage	Daily			
	Check air pressure (50 psi-26 x 12.00-12NHS)	Daily			
	Check lug nuts (torque to 90 ft. lbs. [123 Nm])	30D			
Hydraulic Pump	Wipe clean	30D			
	Check for leaks at mating surfaces	30D			
	Check for hose fitting leaks	Daily			
	Check mounting bolts for proper torque	30D			
	Check the drive coupling for proper alignment and wear	1Y			
	Lubricate pump splines	6M			
Drive Motors	Check for operation and leaks	Daily			
Steering System	Check hardware & fittings for proper torque	6M			
	Grease pivot pins	30D			
	Oil king pins	30D			
	Check steering cylinder for leaks & mounting bolts for proper torque	30D			
Elevating Assembly	Inspect for structural cracks	Daily			
	Check pivot points for wear	30D			
	Check mounting pin pivot bolts for proper torque	30D			
	Check linkage gear for wear	6M			
	Check elevating arms for bending	6M			
	Grease linkage pins	30D			
	Grease linkage gear	30D			

Routine Service Table Key

Interval

Daily=each shift (every day) or every eight hours
30d=every month (30 days) or every 50 hours
3m=every 3 months or 125 hours
6m=every 6 months or 250 hours
1y=every year or 500 hours
2y=every 2 years or 1000 hours

Y=Yes/Acceptable

N=No/Not Acceptable

R=Repaired/Acceptable

COMPONENT	INSPECTIONORSERVICES	INTERVAL	Y	N	R
Chassis	Check hoses for pinch or rubbing points	Daily			
	Check component mounting for proper torque	6M			
	Check welds for cracks	Daily			
Lift Cylinder	Check the cylinder rod for wear	30D			
	Check mounting pin pivot bolts for proper torque	30D			
	Check pivot pin snap rings	30D			
	Check seals for leaks	30D			
	Inspect pivot points for wear	30D			
	Check fittings for proper torque	30D			
	Check the cylinder rod for wear	30D			
Fore/Aft Cylinder	Check mounting pin pivot bolts for proper torque	30D			
	Check seals for leaks	30D			
	Inspect pivot points for wear	30D			
	Check fittings for proper torque	30D			
Side/Side Cylinder	Check the cylinder rod for wear	30D			
	Check mounting pin pivot bolts for proper torque	30D			
	Check seals for leaks	30D			
	Inspect pivot points for wear	30D			
Axle Cylinder	Check fittings for proper torque	30D			
	Check the cylinder rod for wear	30D			
	Check mounting pin pivot bolts for proper torque	30D			
	Check seals for leaks	30D			
	Inspect pivot points for wear	30D			
Bubble Level	Check fittings for proper torque	30D			
	Check bubble and target ring for damage.	Daily			
Entire Unit	Check for and repair collision damage	Daily			
	Check fasteners for proper torque	3M			
	Check for corrosion-remove and repaint	6M			
	Lubricate	30D			
	Check for peeling, missing, or unreadable labels & replace	Daily			
Labels					

Service Report

Date: _____

Owner: _____

Model No: _____ Serial No: _____

Serviced By: _____

Service Interval: _____

Fold Down Guardrails

This procedure is only for passing through door-ways. Guardrails must be returned to proper position before using the machine.

Fold Down Procedure (Figure 4)

Note: When performing the following proce-dures retain all fasteners.

1. Place controller on platform.
2. Starting at the front of the platform, remove nuts, bolts and washers from the top of the front guardrail. Fold the front guardrail down onto the platform.
3. Close and latch the gate.
4. Remove nuts, bolts and washers from the top of the rear guardrail. Fold the rear guardrail down onto the platform being careful to keep gate latched at all times.
5. Remove nuts, bolts and washers from the top of the side guardrails and from the slideout deck midrail. Lift up and fold one side guardrail in so it rests on the deck. Repeat with other side guardrails.

Erection Procedure

1. Raise side guardrails making sure each is pushed down to secure the guardrail in the vertical position.
2. Install bolts, washers and nuts between the side guardrails, tighten securely.
3. Raise rear guardrail assembly, aligning holes and install bolts, washers and nuts. Tighten securely.

⚠

DANGER

⚠

Before entering Platform, guardrails must be securely fastened in their proper position.




Figure 4: Fold Down Guardrails

Transporting Work Platform

By Forklift

NOTE: Forklifting is for transporting only.

⚠

CAUTION

⚠

See specifications for weight of work platform and be certain that forklift is of adequate capacity to lift platform.

Forklift from side of Chassis by lifting under the Chassis Modules (Figure 5).

By Crane

1. Secure straps to Chassis Lifting Lugs only (Figure 5).

By Truck

1. Maneuver the work platform into transport position and chock wheels.
2. Secure the work platform to the transport vehicle with chains or straps of adequate load capacity attached to the chassis tie down lugs (Figure 5).

⚠

CAUTION

⚠

Tie down lugs are not to be used to lift work platform.

Overtightening of chains or straps through tie down lugs may result in damage to work platform.




Figure 5: Transporting Work Platform

Maintenance

⚠ DANGER ⚠

Never perform service on the work platform in the Elevating Assembly area while platform is elevated without first blocking the Elevating Assembly.

DO NOT stand in Elevating Assembly area while installing or removing brace.

⚠ CAUTION ⚠

DO NOT support or raise the front of the platform during any maintenance operation as this may result in damage to the tension members.

Blocking Elevating Assembly (Figure 6)

Installation

1. Park the work platform on firm level ground.
2. Remove Control Module covers.
3. Verify both Emergency Stop Switches are ON, start the engine.
4. Turn Chassis Key Switch to **CHASSIS**.
5. Position Chassis Lift Switch to **UP** and elevate platform approximately 12 inches (305 mm).
6. Place a jackstand with a minimum rating of 4,000 lbs. (1,814 Kg) between the Lower Arm and Chassis just behind the front axle.
7. Push Chassis Lift Switch to **DOWN** position and gradually lower platform until jackstand is secured tightly between Lower Arm and Chassis.

Removal




Figure 6: Blocking Elevating Assembly

1. Push Chassis Lift Switch to **UP** position and gradually raise platform until jackstand can be removed.
2. Remove jackstand.
3. Push Chassis Lift Switch to **DOWN** position and completely lower platform.

Battery Maintenance

⚠ WARNING ⚠

Hazard of explosive gas mixture. Keep sparks, flame, and smoking material away from battery.

Always wear safety glasses when working with batteries.

Battery fluid is highly corrosive. Thoroughly rinse away any spilled fluid with clean water.

Battery Inspection and Cleaning

Check battery fluid level daily, especially if work platform is being used in a warm, dry climate. If the electrolyte level is lower than $\frac{3}{8}$ in. (10 mm) above the plates, add clean, distilled water **only**. Use of tap water with high mineral content will shorten battery life.

The battery should be inspected regularly for signs of cracks in the case, electrolyte leakage and corrosion of the terminals. Inspect cables for worn spots or breaks in the insulation and for broken cable terminals.

Clean the battery when there is signs of corrosion at the terminals or when electrolyte has overflowed during charging. Use a baking soda solution to clean the battery, taking care not to get the solution inside the cells. Rinse thoroughly with clean water. Clean battery and cable contact surfaces to a bright metal finish whenever a cable is removed.