

INSTRUCTION MANUAL

WARNING
IMPORTANT SAFETY RULES
 Please! Carefully study these Safety Rules and Operating Instructions. Make sure all personnel read and understand them completely before using the Up-Right UL Lift.




UP-RIGHT LIFTS

SERIAL NUMBERS 1723 TO 4331

UL-24/30, UL-31/37 & UL-38/44

SAFETY RULES & OPERATING INSTRUCTIONS



SAFETY RULES

Before using the Up-Right Lift, thoroughly inspect it for damage such as cracked welds, loose rivets, hydraulic leaks, damaged control or power cables, and loose or missing fasteners. NEVER use damaged equipment.


- NEVER elevate platform unless all four (4) outriggers have been properly installed. All outrigger screwjack pads must be in contact with a firm surface before the platform is elevated.
- NEVER elevate the platform if it contains more than the rated load of 300 pounds or more than one person.
- NEVER attach overhanging loads to the platform or increase the platform size.
- NEVER use ladders, planks or other devices to increase the height of the platform.
- NEVER use the Up-Right Lift as a freight or personnel elevator.
- NEVER use the UL-24/30 outriggers with the UL-31/37 or UL-38/44 models.
- Check clearances above and below the platform.
- Latch rope across opening after entering platform.
- After use, secure the unit against unauthorized use by turning off the key switch and removing key.

OPERATION

- Read and fully understand this operator's manual.
- Be sure the unit has been properly set up with all four (4) outriggers installed.
- Check for external damage to the mast.
- Plug unit into a 120 V.A.C. 60 Hz power source. (NOTE: Applies to A.C. unit only.)
- Mount the platform using the access ladder.
- Latch rope across entrance after mounting the platform.
- Check for overhead obstructions.
- Turn on the keyswitch located on the side of the pinch shield.
- Lift up on the toggle switch to elevate the platform. Release the toggle switch to stop. Push down on the toggle switch to lower the platform.
- Always check that the area below the platform is clear before lowering the platform.
- After use, secure unit against unauthorized use by turning off key switch and removing key.

SETTING UP THE UP-RIGHT LIFT

A. INSTALLING THE OUTRIGGERS



(1) Remove the outriggers from storage location. (Outrigger storage locations on either side of mast.)



(2) Insert into designated outrigger socket in base.

(3) Push in until locking pin engages hole in end of outrigger. Pull outward on outrigger to ensure engagement. See insert photo (2).



(5) Level the base, using the screwjacks at the end of each outrigger. All four (4) screwjack pads must be in contact with a firm surface before the platform is elevated. Center the bubble in the orbit level on the right side of the base by adjusting the screwjacks at the end of each outrigger.


(4) Repeat the above steps for all other outriggers. Make sure all four (4) locking pins are engaged. (At this point the unit may be moved provided the outrigger screwjacks are fully retracted.)

B. ALTERNATE CONFIGURATION SET UP


When it is necessary to operate the Up-Right Lift next to a wall the outrigger adjacent to the wall may be inserted into the socket past the locking pin.

DANGER

This alternate configuration should be used only when it is necessary to operate the unit next to a wall and there is insufficient distance to the wall to allow full outrigger length. The platform must not be elevated higher than the wall. All four (4) outriggers must be installed.



(1) Once all four (4) outriggers have been properly installed, slide the outrigger adjacent to the wall all the way into the socket by lifting the ring on the locking pin and pushing on the outrigger.
Note: When outrigger next to wall is a side outrigger; remove the outrigger and install on the same side in front outrigger socket tube and slide it all the way into tube.



(2) Position the unit next to the wall and extend the outrigger adjacent to the wall as far as possible. Level the base, using the screwjacks at the end of each outrigger.



(3) Center the bubble in the orbit level on the right side of the base by adjusting screwjacks at end of each outrigger.




(4) All four (4) screwjack pads must be in contact with a firm surface before the platform is elevated.

OPERATION

- Read and fully understand this operator's manual.
- Be sure the unit has been properly set up with all four (4) outriggers installed.
- Check for external damage to the mast.
- Plug unit into a 120 V.A.C. 60 Hz power source. (NOTE: Applies to A.C. unit only.)
- Mount the platform using the access ladder.
- Latch rope across entrance after mounting the platform.
- Check for overhead obstructions.
- Turn on the keyswitch located on the side of the pinch shield.
- Lift up on the toggle switch to elevate the platform. Release the toggle switch to stop. Push down on the toggle switch to lower the platform.
- Always check that the area below the platform is clear before lowering the platform.
- After use, secure unit against unauthorized use by turning off key switch and removing key.

SETTING UP THE UP-RIGHT LIFT

A. INSTALLING THE OUTRIGGERS



(1) Remove the outriggers from storage location. (Outrigger storage locations on either side of mast.)



(2) Insert into designated outrigger socket in base.



(3) Push in until locking pin engages hole in end of outrigger. Pull outward on outrigger to ensure engagement. See insert photo (2).




(5) Level the base, using the screwjacks at the end of each outrigger. All four (4) screwjack pads must be in contact with a firm surface before the platform is elevated. Center the bubble in the orbit level on the right side of the base by adjusting the screwjacks at the end of each outrigger.

(4) Repeat the above steps for all other outriggers. Make sure all four (4) locking pins are engaged. (At this point the unit may be moved provided the outrigger screwjacks are fully retracted.)

B. ALTERNATE CONFIGURATION SET UP

When it is necessary to operate the Up-Right Lift next to a wall the outrigger adjacent to the wall may be inserted into the socket past the locking pin.



(1) Once all four (4) outriggers have been properly installed, slide the outrigger adjacent to the wall all the way into the socket by lifting the ring on the locking pin and pushing on the outrigger.
Note: When outrigger next to wall is a side outrigger; remove the outrigger and install on the same side in front outrigger socket tube and slide it all the way into tube.



(2) Position the unit next to the wall and extend the outrigger adjacent to the wall as far as possible. Level the base, using the screwjacks at the end of each outrigger.



(3) Center the bubble in the orbit level on the right side of the base by adjusting screwjacks at end of each outrigger.




(4) All four (4) screwjack pads must be in contact with a firm surface before the platform is elevated.

DANGER

This alternate configuration should be used only when it is necessary to operate the unit next to a wall and there is insufficient distance to the wall to allow full outrigger length. The platform must not be elevated higher than the wall. All four (4) outriggers must be installed.

DECAL INSTALLATION: READ AND UNDERSTAND These decals before operating Up-Right Lift



NOTE: Decals can be ordered by using part number located by each decal.

OPTIONAL UP-RIGHT LIFT LOADER

WARNING
Ensure Loader Bar is in full contact with a clean level surface.

A. LOADING THE UP-RIGHT LIFT INTO A VEHICLE USING THE OPTIONAL LOADER.




(1) Slide the loader bar, located on the back of the unit, up past the top set of holes and engage the loader pin through the top set of holes *below* the loader bar.




(2) Back the unit up to the vehicle bed until the back of the unit comes in contact with the vehicle bed.




(3) Remove the loader pin and slide the loader bar down until it comes into contact with the vehicle bed.




Then properly engage the loader pin (using the hair pin retainer) in the first available set of holes *above* the loader bar.




(4) Insert an outrigger into the front outrigger socket until the locking pin engages the hole in the end of the outrigger.



(5) Pull upward on the end of the outrigger using the loader bar as a fulcrum until the unit rotates to a horizontal position in the vehicle bed.



(6) Push the base of the unit towards the front of the vehicle bed. The loader bar will slide on the unit until the rear wheels contact the vehicle bed. The unit may then be rolled on the rear wheels and the casters located near the top of the unit.



(7) Remove the outrigger in the front socket and put it in the outrigger storage location.

(8) Secure the unit with rope using the tie down holes located on the base of the unit and at the top of the cage support member.

WARNING
To prevent serious damage to the mast assembly, do not place rope or tie downs across the mast assembly when securing the unit for transportation.

B. UNLOADING THE UP-RIGHT LIFT FROM A VEHICLE USING THE OPTIONAL LOADER.

(1) Unsecure the unit.

(2) Insert the outrigger into the front outrigger socket until the locking pin engages the hole in the front end of the outrigger.

(3) Roll the unit back until the rear wheels are off the edge of the vehicle bed.

(4) Pull downward on the outrigger, allowing the unit to

slide on the loader bar. As the unit stops sliding on the loader bar the unit will rotate upright using the loader bar as a fulcrum. Gradually counterbalance the unit's weight by applying an upward force on the outrigger. This allows the unit to settle gently on the front casters, avoiding undue impact loading on the unit.

(5) Remove the front outrigger and put it in the outrigger storage location.

OPTIONAL UP-RIGHT LIFT LOADER

WARNING
Ensure Loader Bar is in full contact with a clean level surface.

A. LOADING THE UP-RIGHT LIFT INTO A VEHICLE USING THE OPTIONAL LOADER.



(1) Slide the loader bar, located on the back of the unit, up past the top set of holes and engage the loader pin through the top set of holes *below* the loader bar.




(2) Back the unit up to the vehicle bed until the back of the unit comes in contact with the vehicle bed.



(3) Remove the loader pin and slide the loader bar down until it comes into contact with the vehicle bed.



Then properly engage the loader pin (using the hair pin retainer) in the first available set of holes *above* the loader bar.




(4) Insert an outrigger into the front outrigger socket until the locking pin engages the hole in the end of the outrigger.



(5) Pull upward on the end of the outrigger using the loader bar as a fulcrum until the unit rotates to a horizontal position in the vehicle bed.



(6) Push the base of the unit towards the front of the vehicle bed. The loader bar will slide on the unit until the rear wheels contact the vehicle bed. The unit may then be rolled on the rear wheels and the casters located near the top of the unit.



(7) Remove the outrigger in the front socket and put it in the outrigger storage location.

(8) Secure the unit with rope using the tie down holes located on the base of the unit and at the top of the cage support member.

WARNING
To prevent serious damage to the mast assembly, do not place rope or tie downs across the mast assembly when securing the unit for transportation.

B. UNLOADING THE UP-RIGHT LIFT FROM A VEHICLE USING THE OPTIONAL LOADER.

(1) Unsecure the unit.

(2) Insert the outrigger into the front outrigger socket until the locking pin engages the hole in the front end of the outrigger.

(3) Roll the unit back until the rear wheels are off the edge of the vehicle bed.

(4) Pull downward on the outrigger, allowing the unit to


slide on the loader bar. As the unit stops sliding on the loader bar the unit will rotate upright using the loader bar as a fulcrum. Gradually counterbalance the unit's weight by applying an upward force on the outrigger. This allows the unit to settle gently on the front casters, avoiding undue impact loading on the unit.

(5) Remove the front outrigger and put it in the outrigger storage location.

SAFETY RULES AND OPERATING INSTRUCTIONS

SPECIFICATIONS *			
	UL-24/30	UL-31/37	UL-38/44
Platform Height			
(A) Maximum	24 ft.	31 ft.	38 ft.
Platform Capacity	300 lbs.	300 lbs.	300 lbs.
Stored Dimensions			
(B) Vertical Height	79 in.	98 in.	114 in.
(C) Width	29 in.	29 in.	29 in.
Depth	45 in.	45 in.	45 in.
(D) Horizontal Height	45 in.	45 in.	45 in.
(E) Horizontal Length	79 in.	98 in.	114 in.
(F) Diagonal Storage Height	-	79 in.	79 in.
(G) Diagonal Storage Length	-	101 in.	116 in.
Base Dimension with Outriggers extended			
(H) Side to Side	110 in.	146 in.	146 in.
(I) Front to Back	92 in.	135 in.	135 in.
Weight			
Without Outriggers & Screwjacks	512 lbs.	624 lbs.	664 lbs.
Set of Outriggers & Screwjacks	51 lbs.	54 lbs.	54 lbs.
Additional Weight for D.C. Option	53 lbs.	53 lbs.	53 lbs.
Safety Railing Height	42 in.	42 in.	42 in.
Toe Board Height	4 in.	4 in.	4 in.
Lift System			
A.C. Electric Motor	120 Volts, 60 Hz		
D.C. Electric Power Source	1-12 Volt Battery, Grp. 27, 105 Amp./Hrs.		
Battery Charger	Automatic, 120 Volt A.C., 60 Hz. Output: 10 Amps, 12 Volts D.C.		

*All specifications subject to change without notice.



MAINTENANCE AND ROUTINE SERVICE

Service Operation	Service Interval		
	1 Month	3 Month	1 Year
1. Check oil level	X		
2. Inspect and adjust sequence straps slack		X	
3. Check bubble level accuracy		X	
4. Lubricate lift chains, chain sheaves		X	
5. Change hydraulic oil (Mobile DTE-13)			X
6. Contactor malfunction check	X		
7. Battery fluid level	X		

For proper service procedures, see Up-Right Lift Service Manual, Part No. 62316-001-00.

FOR MORE INFORMATION

UpRight

USA
TEL: (800) 926-5438 or (209) 896-5150
FAX: (209) 896-9012
1775 Park St., Selma, CA 93662


EUROPE
TEL: (353) 1-285-3333
FAX: (353) 1-284-0015
Pottery Road, Dunloaire, Ireland

Local Distributor:

SAFETY RULES AND OPERATING INSTRUCTIONS

SPECIFICATIONS *			
	UL-24/30	UL-31/37	UL-38/44
Platform Height			
(A) Maximum	24 ft.	31 ft.	38 ft.
Platform Capacity	300 lbs.	300 lbs.	300 lbs.
Stored Dimensions			
(B) Vertical Height	79 in.	98 in.	114 in.
(C) Width	29 in.	29 in.	29 in.
Depth	45 in.	45 in.	45 in.
(D) Horizontal Height	45 in.	45 in.	45 in.
(E) Horizontal Length	79 in.	98 in.	114 in.
(F) Diagonal Storage Height	-	79 in.	79 in.
(G) Diagonal Storage Length	-	101 in.	116 in.
Base Dimension with Outriggers extended			
(H) Side to Side	110 in.	146 in.	146 in.
(I) Front to Back	92 in.	135 in.	135 in.
Weight			
Without Outriggers & Screwjacks	512 lbs.	624 lbs.	664 lbs.
Set of Outriggers & Screwjacks	51 lbs.	54 lbs.	54 lbs.
Additional Weight for D.C. Option	53 lbs.	53 lbs.	53 lbs.
Safety Railing Height	42 in.	42 in.	42 in.
Toe Board Height	4 in.	4 in.	4 in.
Lift System			
A.C. Electric Motor	120 Volts, 60 Hz		
D.C. Electric Power Source	1-12 Volt Battery, Grp. 27, 105 Amp./Hrs.		
Battery Charger	Automatic, 120 Volt A.C., 60 Hz. Output: 10 Amps, 12 Volts D.C.		

*All specifications subject to change without notice.



SAFETY RULES AND OPERATING INSTRUCTIONS

SAFETY RULES AND OPERATING INSTRUCTIONS

INSTRUCTION MANUAL

WARNING
IMPORTANT SAFETY RULES
Please! Carefully study these Safety Rules and Operating Instructions. Make sure all personnel read and understand them completely before using the Up-Right UL Lift.

UR

UP-RIGHT
LIFTS

SERIAL NUMBERS 1723 TO 4331

UL-24/30, UL-31/37 & UL-38/44

SAFETY RULES & OPERATING INSTRUCTIONS



SAFETY RULES

Before using the Up-Right Lift, thoroughly inspect it for damage such as cracked welds, loose rivets, hydraulic leaks, damaged control or power cables, and loose or missing fasteners. NEVER use damaged equipment.

- NEVER elevate platform unless all four (4) outriggers have been properly installed. All outrigger screwjack pads must be in contact with a firm surface before the platform is elevated.
- NEVER elevate the platform if it contains more than the rated load of 300 pounds or more than one person.
- NEVER attach overhanging loads to the platform or increase the platform size.
- NEVER use ladders, planks or other devices to increase the height of the platform.
- NEVER use the Up-Right Lift as a freight or personnel elevator.
- NEVER use the UL-24/30 outriggers with the UL-31/37 or UL-38/44 models.
- Check clearances above and below the platform.
- Latch rope across opening after entering platform.
- After use, secure the unit against unauthorized use by turning off the key switch and removing key.

MAINTENANCE AND ROUTINE SERVICE

Service Operation	Service Interval		
	1 Month	3 Month	1 Year
1. Check oil level	X		
2. Inspect and adjust sequence straps slack		X	
3. Check bubble level accuracy		X	
4. Lubricate lift chains, chain sheaves		X	
5. Change hydraulic oil (Mobile DTE-13)			X
6. Contactor malfunction check	X		
7. Battery fluid level	X		

For proper service procedures, see Up-Right Lift Service Manual, Part No. 62316-001-00.

FOR MORE INFORMATION

UpRight

USA
 TEL: (800) 926-5438 or (209) 896-5150
 FAX: (209) 896-9012
 1775 Park St., Selma, CA 93662

EUROPE
 TEL: (353) 1-285-3333
 FAX: (353) 1-284-0015
 Pottery Road, Dunloire, Ireland

Local Distributor: